

BUCKINGHAM MFG.

P/N's RFPDELUXE; RFPBASIC; RFPREDIRECT

Instructions / Warnings

Warning: Do not use this product if you cannot understand and follow the instructions and warnings that come with it and complete all necessary functions.

The Buckingham P/N RFPBASIC, P/N RFPREDIRECT and P/N RFPDELUXE (consists of P/N RFPBASIC [Fig. 1] and P/N RFPREDIRECT [Fig. 2]) provides a temporary system that allows the user to set a lifeline and Re-Direct lines from the ground to keep them 100% Fall Protected while ascending a ladder, working on the ladder or elevated surface and descending the ladder.

Fig. 1



Fig. 2



Note: hardware / material colors and or lengths may vary from that shown.

Review of Job Site

1. Observe and inspect the work area.
2. Determine installation location and locate suitable anchors (anchors need to be located on the opposite side of the structure from the work being performed).
3. Determine Application needed.
 - a. **Basic Application** (Pages 3 - 6) (P/N RFPBASIC)
 - Work area is easily reached from ladder or minimal access to the roof is required
 - No chance of a swing fall
 - b. **Re-Direct Application** (Pages 6 - 12) (P/N RFPDELUXE)
 - Work area is close to a peak or edge
 - Chance of swing fall
 - Chance of lifeline sliding off peak or edge
 - c. **Load Sharing Application** (Pages 6 - 12) (P/N RFPDELUXE)
 - Questionable anchorage. Must share the load between multiple anchors.
 - Set-up the same as Re-Direct Application ('b' above)
 - d. **Load Sharing / Re-Direct Application** (Pages 6 - 12) (P/N RFPDELUXE)
 - Questionable anchorage. Must share the load between multiple anchors.
 - Work area is close to a peak or edge
 - Chance of swing fall
 - Chance of lifeline sliding off peak or edge
 - Set-up the same as Re-Direct Application ('b' above)

4. **Suitable Anchorages:**

▪ **Trees**

Trees may be used as a suitable anchor when the following criteria is met:

- Healthy, with no signs of rot or decay.
- Minimum of 6" diameter trunk (measured 6" up from the ground).
- Stable ground.
- Packed / compressed soil (avoid loose soil).
- Always keep anchor point at ground level.
- Work practice is approved by employer.

▪ **Vehicle**

Vehicles may be used as a suitable anchor when the following criteria is met:

- Has a minimum weight of 4,000 lbs.
- Is in good repair.
- Keys have been removed from ignition and vehicle has been locked out.
- Has at least a Class III hitch and the user **ONLY** connects to the hitch or similarly rated tow hooks.
- Is parked on a stable and level surface with wheels chocked.
- Has parking brake engaged.
- Work practice is approved by employer.

NOTE: If using a vehicle for an anchorage; prior to setting up and using the Buckingham RFP, ensure the vehicle is properly Locked Out in accordance with all applicable OSHA regulations and/or company policies.


▪ **Utility Pole**

Utility poles may be used as a suitable anchor when the following criteria is met:

- Well maintained pole that is free of rot and decay.
- Minimum 30, class 4 pole.
- Pole is straight (avoid crooked and leaning poles).
- Stable ground.
- Packed / compressed soil (avoid loose soil)
- Always keep anchor point at ground level.
- Work practice is approved by employer.

A. Installing the P/N 39Y11Q2-150 Lifeline (Basic Application – see Fig. 1 for components):

1. Determine ladder placement to reach the work area.
2. Ensure the area behind the structure is clear of objects, persons, animals or anything that the throw bag could contact / damage / injure.
3. Ensure the path of the throw bag and line are clear of any powerlines, phone line or other utility cables and wires.
4. Follow the BuckLaunch product instructions and launch the throw bag with throw line attached over the structure and towards the anchor or the work area (Fig. 3). When launching the throw bag ensure the path and area where the throw bag will land is clear as noted in steps 2 and 3 above.
5. Attach the end of the throw line to the anchor eye of the lifeline and pull over the structure towards the anchor (Fig. 4 - 5). Note: If the BuckArrester is installed on the lifeline you must maintain the position of the BuckArrester so that when you pull the lifeline over the structure it will remain where you can access it. If the BuckArrester is not installed on the lifeline, follow Section E below.



B. Installing P/N 3904J12-8 Lifeline Temporary Anchor Strap:

1. Choose a suitable fall arrest anchor point (see 4 under Review of Jobsite above). Anchor needs to be located such that when the lifeline is installed the position of the anchor will keep the lifeline in the work area, away from any edges and prevent a swing.
2. Wrap temporary anchor strap around suitable anchor (Fig. 6).
3. Insert the small D-ring through the larger D-ring (Fig. 7).
4. Pull end of strap with smaller D-ring through larger D-ring choking the strap around the anchor (Fig. 8).
Note: On a smaller diameter anchor, it may be necessary to wrap the strap around the anchor multiple times before choking the strap (Fig. 9).




C. Attaching Lifeline to Temporary Anchor Strap:

1. Untie throw line from eye of lifeline (Fig. 10).
2. Attach P/N 5005 Carabiner to eye of lifeline (Fig. 11).
3. Connect the carabiner to the small D-ring on the temporary anchor strap (Fig. 12).





D. Installing the RFP Lifeline Flag:

1. Open the hook & loop fastener strap located at the top of the flag (Fig. 13).
2. Wrap the hook & loop fastener strap around the previously installed lifeline or re-direct line and secure the hook & loop fastener together (Fig. 14). Note: Install the RFP lifeline flag in a location that is close to the anchor point and easily seen.



E. Installing the Ladder:

1. Following the ladder manufacturer's instructions and your employer's work practices, install the ladder in the desired location to reach the work area (Fig. 15). Note: The ladder must be installed at the proper angle (approx. 75.5° or 4:1 ratio) with a minimum of 3' (but less than 6') extended past the roof line. Failure to properly install the ladder could result in your serious injury or death.



F. Attaching the P/N 5004BQ1 BuckArrester Mobile Fall Arrester (MFA) to the Lifeline:

1. Ensure the UP arrow on the frame of the BuckArrester is facing the top of the ladder and up the lifeline (Fig. 16 - 17).
2. Rotate the cam up into the open position (Fig. 18).
3. Insert the tail of the lifeline through the top of the BuckArrester channel between the frame and the cam (Fig. 19 - 20).
4. Slide the BuckArrester into the desired position on the lifeline (Fig. 21).

Top of the Ladder / Lifeline Fig. 17



Fig. 18



Fig. 19



Fig. 20



Fig. 21



G. Securing the Tail of the Lifeline to the Ladder:

1. Pull the slack out of the lifeline (pulling away from anchor) and form a loop in the lifeline in front of the 2nd or 3rd rung (on the bottom) on the ladder (Fig. 22).
2. Wrap the loop behind the rung (Fig. 23).
3. Bring loop around behind the doubled lifeline and back through the doubled loop formed (Fig. 24 - 25).
4. Pull knot tight (Fig. 26).

Fig. 22



Fig. 23



Fig. 24



Fig. 25




Fig. 26



Note: Securing the lifeline to the ladder allows for the user to remove slack from the lifeline.

H. Attaching BuckArrester to Harness:

1. Open the Integral Attachment Carabiner gate (Fig. 27).
2. Connect the carabiner to the Harness Sternal D-ring (Fig. 28).
3. Ensure the carabiner gate is completely closed (Fig. 29).

Fig. 27



Fig. 28




Fig. 29



Note: When ascending and descending the ladder the BuckArrester Mobile Fall Arrester (MFA) will freely follow the user up and down the lifeline. If the BuckArrester should catch on the rope (the BuckArrester may catch on the lifeline prematurely if the user is climbing too fast or if their body is too far away from the ladder) the user should stop and release the cam of the BuckArrester, (to release, take the tension off of the lanyard and press the cam towards the body of the BuckArrester) reposition the BuckArrester below your sternal connection and then continue descending down the ladder. Always Follow employer's work practices and maintain 3 points of contact while ascend and descending the ladder.

Tip for descending:

Placing your hand in the center of the rung behind the lifeline will guide it away from the rung preventing the BuckArrest from contacting the rung and accidentally engaging.

Fig. 30




Fig. 31



Fig. 32





P/N RFPREDIRECT

I. Determining Attachment Point for Re-Direct Line

Note: The Re-Direct Application (Fig. 2) is used in conjunction with the Basic Application (Fig. 1)

1. Determine placement of the ladder to reach the work area.
2. Review the work area and determine if the lifeline will be near an edge or has the potential for a swing fall based on the location of a suitable anchor for the lifeline (Fig. 33)
3. If the lifeline is near an edge or has the potential for a swing fall determine suitable attachment point(s) for the Re-Direct line(s) that will keep lifeline from an edge and prevent a swing fall (Fig. 34). Note: It may be necessary to use multiple Re-Direct lines
4. Once you have the determined position for the Re-Direct lines, estimate the approximate distance from the lifeline anchor to the first position of a Re-Direct line attachment and install a P/N P9C6A-10-18 lifeline prusik in this location (see section I below).
5. If a second Re-Direct line is needed, estimate the approximate distance from the lifeline anchor to the position of second Re-Direct line attachment and install a P/N P9C6A-10-18 lifeline prusik in this location (see section I below).



J. Attaching Lifeline Prusik to Lifeline:

1. Pass the prusik loop behind the lifeline and then pass the end with the stitching over the line and through the opposite side of the prusik forming the first wrap (Fig. 35 - 36).
2. Next pass the end with the stitching over the line and through the opposite side of the prusik a second time forming the second wrap (Fig. 37 - 38).
3. Again, pass the end with the stitching over the line and through the opposite side of the prusik a third time forming the third wrap (Fig. 39 - 40).
4. Finally pass the end with the stitching over the line and through the opposite side of the prusik a fourth time forming the fourth and final wrap (Fig. 41 - 42).
5. Dress / set the prusik by aligning the wraps of the prusik around the line while pulling prusik tight (Fig. 43).

Fig. 35




Fig. 36



Fig. 37




Fig. 38



Fig. 39




Fig. 40



Fig. 41





Fig. 42



Fig. 43



K. Attaching the Re-Direct Line to the Lifeline Prusik:

1. Insert the girth hitch loop end of the Re-Direct line through the loop of the lifeline prusik previously attached to the lifeline (Fig. 44 - 45).
2. Insert the tail end (end opposite the girth hitch loop) of the Re-Direct line through the opening of the girth hitch loop (Fig. 46).
3. Feed the tail of the Re-Direct line through the girth hitch loop pulling the full length of the Re-Direct line through the girth hitch loop (Fig. 47 - 48).
4. Push the stitching of the girth hitch loop through the girth hitch loop and pull down tight (Fig. 49 - 50). Note: the prusik must be tight to grab the rope. Verify the prusik is set by pulling the prusik and lifeline in opposite directions. The prusik must not slide.

Fig. 44





Fig. 45



Fig. 46






Fig. 47




Fig. 48




Fig. 49



Fig. 50

L. Tying the Slip Knot:

1. Form a loop in the lifeline just below the lifeline prusik (Fig. 51 - 52).
2. Form a second loop in the lifeline below the first loop and insert through the first loop (Fig. 53 - 54).
3. Tighten the first loop onto the second loop from above (Fig. 55).
4. Position the lifeline prusik on top of the slip knot and re-tighten the prusik in place (Fig. 56).

Notes: Slip knot is used to prevent the prusik from slipping if the prusik gets caught on the eaves / gutter when pulling lifeline onto the roof. The user must not connect to the slip knot.




Fig. 51



Fig. 52



Fig. 53



Fig. 54



Fig. 55



Fig. 56

M. Installing the Lifeline with Re-Direct Line(s) Installed:

1. Ensure the area behind the structure where the anchor is located is clear of objects, persons, animals and anything that the throw bag could contact / damage / injure.
2. Ensure the path of the throw bag and line are clear of any powerlines, phone lines or other utility cables and wires.
3. Follow the BuckLaunch product instructions and launch the throw bag with throw line attached over the structure and towards the anchor or the work area (Fig. 57). When launching the throw bag ensure the path and area where the throw bag will land is clear as noted in steps 1 and 2 above.
4. Attach the end of the throw line (with the Re-Direct lines already installed and positioned in desired locations) to the anchor eye of the lifeline and the tail of the Re-Direct line(s) (Fig. 58) and pull over the structure towards the anchor (Fig. 59 - 60).
5. Untie the throw line from the lifeline and Re-Direct lines.




Fig. 57




Fig. 59





Fig. 60

N. Positioning the Re-Direct Prusik on Structure:

1. Slowly pull the end of the lifeline to position the lifeline prusik with the Re-Direct line attached in the desired position.
2. Using step G (above) loosely tie off the opposite end of the lifeline to the ladder to prevent the lifeline prusik with Re-Direct line attached from being pulled too far over the structure.


O. Attaching the Anchor Prusik to Re-Direct / Load Sharing Line:

1. Pass the anchor prusik behind the Re-Direct line and then pass the end with the ring over the line and through the opposite side of the prusik forming the first wrap (Fig. 61 - 62).
2. Next pass the end with the ring over the line and through the opposite side of the prusik a second time forming the second wrap (Fig. 63 - 64).
3. Again, pass the end with the ring over the line and through the opposite side of the prusik a third time forming the third wrap (Fig. 65 - 66).
4. Finally pass the end with the ring over the line and through the opposite side of the prusik a fourth time forming the fourth and final wrap (Fig. 67 - 68).
5. Dress / set the prusik by aligning the wraps of the prusik around the line while pulling prusik tight (Fig. 69). Note: the prusik must be tight to grab the rope. Check the prusik to verify it is tight and verify it is set by pulling the prusik and lifeline in opposite directions. The prusik must not slide.



P. Installing P/N 3904Q2-8 Re-Direct Line Temporary Anchor Strap:

1. Choose a suitable fall arrest anchor point (see 4 under Review of Jobsite above). Anchor needs to be located such that when the Re-Direct line is installed, the position of the anchor will keep the lifeline in the work area, and away from any edges to prevent a swing.
 2. Wrap temporary anchor strap around suitable anchor (Fig. 70)
 3. Insert the small D-ring through the larger D-ring (Fig. 71)
 4. Pull end of strap with smaller D-ring through larger D-ring choking the strap around the anchor (Fig. 72)
- Note: On a smaller diameter anchor, it may be necessary to wrap the strap around the anchor multiple times before choking the strap (Fig. 73).



Q. Attaching Re-Direct Line to Temporary Anchor Strap Using the Anchor Prusik:

1. Attach P/N 5005 Carabiner to ring of the anchor prusik previously installed on the Re-Direct line in Section M (Fig. 74).
2. Connect the carabiner to the small D-ring on the temporary anchor strap (Fig. 75).




R. Attaching Lifeline Prusik to Lifeline on Anchor end:

1. Follow Section I above to install the lifeline prusik on the anchor end of the lifeline.


S. Installing P/N 3904J12-8 Lifeline Temporary Anchor Strap:

1. Choose a suitable Fall Arrest anchor point. Anchor needs to be located such that when the lifeline is installed, the position of the anchor will keep the lifeline in the work area, and away from any edges to prevent a swing.
2. Wrap temporary anchor strap around suitable anchor (Fig. 76)
3. Insert the small D-ring through the larger D-ring (Fig. 77)
4. Pull end of strap with smaller D-ring through larger D-ring choking the strap around the anchor (Fig. 78)
Note: On a smaller diameter anchor, it may be necessary to wrap the strap around the anchor multiple times before choking the strap (Fig. 79).





T. Attaching Lifeline to Temporary Anchor Strap Using the Lifeline Prusik:

1. Attach P/N 5005 Carabiner to the lifeline prusik previously installed on the lifeline in Section P (Fig. 80).
2. Connect the carabiner to the small D-ring on the temporary anchor strap (Fig. 81).




U. Adjusting the Location of the Re-Direct Line

1. **To Adjust the Location of the Re-Direct Lines Closer to the Anchors:**
 - a. Pull the lifeline through the lifeline prusik from the tail end until the Re-Direct prusik is at the desired location on the roof and tighten prusik (Fig. 82).
 - b. Using Section T below, tie an overhand knot in the tail of the lifeline behind the prusik. Note: The overhand knot is used to maintain the position of the prusik while there is slack in the line and the lines are being moved into position.
 - c. Pull the Re-Direct line through the anchor prusik from the tail end to remove the slack in the Re-Direct line and tighten prusik (Fig. 83).
 - d. Again, using Section T below, tie an overhand knot in the tail of the Re-Direct line behind the prusik. Note: The overhand knot is used to maintain the position of the prusik while there is slack in the line and the lines are being moved into position.
 - e. Follow Section E – H above to complete set up.




2. To Adjust the Location of the Re-Direct Lines Away from the Anchors:

- Pull the lifeline through the lifeline prusik from the ladder side until the Re-Direct line attached to the lifeline is at the desired location on the roof and tighten prusik (Fig. 84).
- Using Section T below, tie an overhand knot in the tail of the lifeline behind the prusik. Note: The overhand knot is used to maintain the position of the prusik while there is slack in the line and the lines are being moved into position.
- Pull the Re-Direct line through the anchor prusik from the ladder side of Re-Direct line to form slack in the Re-Direct line and tighten prusik (Fig. 85).
- Again, using Section T below, tie an overhand knot in the tail of the Re-Direct line behind the prusik. Note: The overhand knot is used to maintain the position of the prusik while there is slack in the line and the lines are being moved into position.
- Move to the opposite side of the structure and pull on the lifeline to remove slack.
- Follow Section E – H above to complete set up.



V. Tying the Overhand Knot:

- Form a loop in the tail of the lifeline / redirect line just behind the prusik (Fig. 86).
- Bring the loop around in front of the doubled rope (Fig. 87).
- Then bring loop behind the doubled rope and into the loop formed by step 2 (Fig. 88).
- Pull knot tight (Fig. 89).



W. Installing RFP Lifeline Flag:

1. Follow section D above to install the RFP lifeline flag(s) onto the re-direct line(s).

Inspect Prior To Each Use: Inspection should occur prior to each use by the user and at a minimum of once a year by a competent person. Carefully inspect for indications of wear, deterioration, or impact loading. The inspection should include, but not be limited to, inspecting for:

Rope Inspection:

Inspection of your rope should be a continuous process of observation before, during, and after each use.

- Inspect rope for signs of excessive wear, abrasions, broken or pulled strands, burns, cuts, frayed strands, hockling, ice buildup, kinks, knots in any given area of the rope. A pulled strand should be re-threaded into the rope if possible, otherwise it may snag on a foreign object during use.
- Both inner and outer fibers contribute to the ropes strength. If either is worn, the rope will naturally be weakened.
- Inconsistent texture or stiff areas of rope indicate excessive dirt or grit embedded in the rope or rope has been exposed to a shock load. A hard or compacted rope indicates reduced strength.
- Inconsistent diameter (flat areas, bumps, or lumps) indicates core or internal damage from overloading or shock loading.
- With use, all ropes become dirty. Inspect for areas of discoloration that could have been caused by chemical contamination and may result in the rope becoming brittle or stiff.
- Glossy or glazed areas that generally indicate signs of heat damage.
- Rope cover is not damaged, missing or torn, splicing, whipping is in place, stitching is free of defects and stitched eyes have a protective cover (shrink tube) over the stitching.
- Contrasting color warning center / core is exposed

If any evidence of wear, deterioration or impact loading as outlined is observed, immediately cease use, destroy the product and replace it with new equipment. Should any unusual conditions not outlined above be observed, or you have reasonable doubt about a particular condition, remove the equipment from service and notify your Supervisor, Safety Director or contact Buckingham Mfg. for clarification.

See photos below for rope examples displaying a variety of conditions indicated above:



Pulled Strand



Broken or Cut Strands



Inconsistent Diameter / Compacted Area



Melted / Glossy or Glazed Strands



Excessive Abrasion / Wear
Contrasting Core visible

Carabiner - Inspect to ensure:

- Component is free of cracks, distortion, corrosion, or nicks.
- The locking gate operates freely and smoothly, and automatically returns to the locked position (Note: Light oil lubrication such as WD-40™ may be used in pivoting areas).

5004BQ1 BuckArrester Mobile Fall Arrester (MFA) – Inspect to ensure:

- Component is free of cracks, distortion, corrosion, or nicks.
- The arrow on the BuckArrester is pointing to the anchor / top of ladder.
- Proper operation of the device.
- Refer to these as well as the Mobile Fall Arrester Instructions and Warnings for component Inst / Warn.

Harness Inspection:

- webbing cuts, kinks, abrasions, burns, excessive swelling, excessive wear, discoloration, cracks, charring, broken fibers, loose stitching, chemical or physical exposures, and buckle holes in strap are not damaged.
- loose, bent or pulled rivets, bent grommets, and broken, cut or burned threads.
- tongue of buckle does not bind on buckle frame.
- nicks, cracks, distortion, excessive wear or corrosion of hardware (buckle, "D"-ring, etc.)
- Refer to these as well as the Harness Instructions and Warnings.

NOTE: Buckingham harnesses are equipped with an impact load indicator label that is designed to deploy upon arresting a fall. An impact load will tear the thread exposing this label making the text visible. If you can see the text, the harness has been impact loaded. If any evidence of wear, deterioration or impact loading as outlined is observed, immediately cease use, destroy the product, and replace it with new equipment. Should any unusual conditions not outlined above be observed, or you have reasonable doubt about a particular condition, remove the equipment from service and notify your Supervisor, Safety Director or contact Buckingham Mfg. for clarification. Failure to carefully and completely inspect your equipment could result in serious injury or death.

Temporary Anchor Inspection:

- webbing cuts, kinks, abrasions, burns, excessive swelling, excessive wear, discoloration, cracks, charring, broken fibers, loose stitching, chemical or physical exposures.
- broken, cut or burned threads.
- nicks, cracks, distortion, excessive wear or corrosion of hardware (Rings, "D"-ring, etc.)
- Refer to these as well as the Temporary Anchor Instructions and Warnings.

BuckLaunch:

- Refer to Buckingham P/N 230422 BuckLaunch Instructions / Warnings.

Ladder:

- Refer to the Ladder Manufacturer's Instructions / Warnings for inspection criteria of your ladder

Warnings:

- Know the job and the regulations governing performance requirements and select the proper equipment.
- Read carefully, understand, and heed these and all other included instructions, warnings, and cautions before using this equipment. Failure to do so could result in your serious injury or death. If any evidence of wear or deterioration as outlined above is observed, immediately cease use, destroy the product, and replace it with new equipment.
- This equipment is intended for use by properly trained professionals only.
- Employer – instruct employees as to proper use, warnings, and cautions before use of this equipment.
- Never climb over the peak, and edge or any point on the structure that would cause the "UP" arrow to face down towards the ground or a lower level. The "UP" arrow must always point up.
- Do not overload the rope or the system.
- Only use this lifeline with the attached BuckArrester Mobile Fall Arrester (MFA). Never attach an additional MFA or similar device as Buckingham cannot guarantee rope will properly compliment the device and function as designed.
- All affixed labels should be left in place and all instructional material kept for future reference.
- To eliminate the potential for gate of the carabiner attached to the BuckArrester from opening / releasing, ensure the carabiner is positioned so that the gate is never load bearing (i.e. never lean into the ladder so far as to press the carabiner gate against a surface while ascending, descending, or working from the ladder).
- This product is designed to be used by a person with a maximum weight of 310 lbs. when fully equipped. Tested in accordance with ANSI Z359.15
- Avoid contact of this equipment with sharp edges or pointed tools, high temperature surfaces, welding or other heat sources.
- Destroy any and all equipment subjected to impact loading.
- Only Buckingham Mfg. Co., or those authorized in writing by Buckingham Mfg. Co., may make repairs to this equipment.
- Product covered under these instructions / warnings should not be resold / redistributed or re-used after use by original user.

If any evidence of wear or deterioration as outlined is observed, immediately cease use, and replace with new equipment. Should any unusual conditions not outlined above be observed, or you have reasonable doubt about a particular condition, remove the equipment from service and notify your Supervisor, Safety Director, or contact Buckingham Mfg. Co. for clarification.

Cleaning / Storage Instructions:

A dirty product should be washed and rinsed in clean water, then dried. Do not store near solvents, corrosive chemicals or at extreme temperatures. Inspect your equipment carefully before use. This product should be stored in a clean and dry environment, out of direct sunlight and away from extreme climate conditions. Ropes should be stored on racks or hooks to provide ventilation and should never be stored on concrete or dirt surfaces.

Patented, for more information, visit BuckinghamMFG.com/Patents.

STATEMENT of OBSOLESCENCE:

Precise “useful life expectancy” or “shelf life” for this product is not specified, as the degree of use, conditions of use, and the degree of care and storage determines useful life. All users maintain responsibility to select proper equipment for the job, be properly trained in its use, and ensure all personnel support equipment passes inspection before each use. Upon evidence of defects, damage or deterioration, all equipment shall be removed from service immediately and tagged or marked as unusable or destroyed. Additionally, all equipment shall be inspected on a regular basis not to exceed one year by a Competent Person, as defined by OSHA/ANSI, to verify that the equipment is safe for use. In the event of any question or concern regarding the condition of such equipment, users shall remove the equipment from service for further inspection. All users must comply with OSHA/ANSI/ASTM standards prior to and in using such equipment. For more information regarding safe and appropriate use of equipment, please contact Buckingham Manufacturing at 1-800-937-2825.

INTERNATIONAL USERS:

Notwithstanding the above, please know that certain international jurisdictions require manufacturers of equipment to provide customers with a maximum useful lifespan (sometimes referred to as a “Statement of Obsolescence”). To the extent required, Buckingham personal protective equipment manufactured from synthetic fiber materials including but not limited to items such as webbing and/or rope are subject to a maximum useful lifespan of ten (10) years from the date of manufacture. As stated above proper usage, storage, maintenance, and care impacts the useful lifespan of equipment. Extreme circumstances may require that product must be retired after only one use. This statement is made in conformance and compliance with BS EN 365:2004. International users must ensure that product inspections are completed by Competent Persons as defined by international standards including but not limited to British Standard (“BS”). If equipment fails any inspections, it must be immediately withdrawn from service and destroyed. For more information regarding safe and appropriate use of equipment, please contact Buckingham Manufacturing at 1-800-937-2825.

OUR GUARANTEE:

We guarantee the equipment we manufacture to be free from defects in material and workmanship. We will repair any equipment deemed to be defective which is returned to us by the original purchaser. However, this guarantee is void if any product is changed or altered in any way, or if the product is used in a manner other than for which it is intended. This express guarantee supersedes all other expressed or implied guarantees, obligations or liabilities. There are no implied warranties of merchantability or fitness for a particular purpose and as such, all implied warranties are specifically disclaimed.

LIMITATION ON LIABILITY:

In no event will Buckingham or buyer be liable to the other for lost revenues, lost profits or any other indirect, consequential, special or punitive losses or damages, however caused, whether in action for breach of contract, strict liability, tort, or otherwise, even if advised of the possibility of such losses or damages. In no event will Buckingham’s liability exceed the total amount paid by the buyer to Buckingham for the product or equipment giving rise to such claim(s).

Please see other terms and conditions relating to this product at <https://buckinghammfg.com/terms-conditions/>

REGISTRATION:

Before use of the product, ensure to register and confirm the product at www.buckinghammfg.com/register.

BUCKINGHAM MFG.

Binghamton, NY
www.buckinghammfg.com
1-800-937-2825