



BUCKINGHAM MFG.

BuckLaunch™ Replacement Tubing and Pouch Installation Instructions


These Installation Instructions only describe replacement of the pouch and elastic tubing on the BuckLaunch™. Please refer to “BuckLaunch™ Instructions / Warnings” for use and safety information.

The Buckingham PN 1027GS BuckLaunch™ Replacement Tubing and Pouch is a replacement component for Buckingham PN 1027G BuckLaunch™ or Buckingham PN 1027GH BuckLaunch™ Replacement Head (Fig. 1).




Removal of Tubing and Pouch

1. With your fingers, flatten the tubing against the arm.
2. Gently roll or slide the tubing through the gap and out of the eye. (Fig. 2 & 3)
3. Repeat on the other side.



Installation of Replacement Tubing and Pouch

1. Lay out the tubing, pouch, and head oriented as shown in Fig. 1.
2. With your fingers, flatten the tubing against the arm.
3. Gently roll or slide the tubing through the gap and into the eye. (Fig. 2 & 4)
4. Repeat on the other side.
5. Pick up the assembly by the base and pull the elastic tubing down so that the balls rest on top of the eyes.
6. Compare the completed assembly with Fig. 1. Refer to “Removal of Tubing and Pouch” above if the pouch must be removed to correct the orientation.



Buckingham Mfg. Co.

Binghamton, NY

www.buckinghammfg.com

1-800-937-2825

Information contained in these written instructions supersedes all other information (written, audio, video etc.) produced by Buckingham Mfg. prior to the revision date of this document.