

BUCKINGHAM MFG.

P/N LRS-4

Retro Chafe Keeper Installation Instructions

Warning: Do not use this product if you cannot understand and follow the instructions and warnings that come with it and complete all necessary functions.



Please consult with your physician prior to using this product. Do not use this product under the influence of drugs or alcohol.

The Retro Chafe Keeper kit (P/N LRS-4) is intended for use for those users that feel the dorsal fall arrest attachment adjusts too easily. Note: Attachment of the Retro Chafe Keeper requires more force be exerted to relocate the dorsal fall arrest attachment.




Note: Do Not assemble the Retro Chafe Keepers until they are in place on the harness, once assembled they cannot be unassembled and reused.

1. Position harness on a flat surface with the shoulder straps of the harness on top and the Dorsal Fall Arrest Attachment facing up (Fig. 1)
2. Below the Fall Arrest attachment and above the single chafe slot pull the two webbing straps away from the chafe to form a loop. Insert one half of the retro keeper under the loop (Fig.2)
Note: The two halves of the Retro Chafe Keeper are identical, each with one tab and one slot.
3. Position one half of the Retro Chafe Keeper under both straps ensuring that the two webbing straps are inside the retro keepers channel (Fig. 3a – 3b)
4. Position second half of Retro Chafe Keeper on top of the first half aligning the tab and slot of one half with the slot and tab of the second half (Fig. 4). Note: Ensure the Retro Chafe Keepers are aligned properly and keeper ends are free from webbing that may be caught during assembly.



(Fall Arrest options may vary from that shown)

5. Firmly press the two halves of the Retro Chafe Keeper together ensuring that they are fully engaged and locked together. Check to make sure the webbing straps move through the Retro Chafe Keeper and are not pinched between the two halves (Fig. 5).
6. Pull the webbing back through the Retro Chafe Keeper to remove the loop previously formed in step 2 (Fig. 6).



STATEMENT of OBSOLESCENCE:

Precise “useful life expectancy” or “shelf life” for this product is not specified, as the degree of use, conditions of use, and the degree of care and storage determines useful life. All users maintain responsibility to select proper equipment for the job, be properly trained in its use, and ensure all personnel support equipment passes inspection before each use. Upon evidence of defects, damage or deterioration, all equipment shall be removed from service immediately and tagged or marked as unusable or destroyed. Additionally, all equipment shall be inspected on a regular basis not to exceed one year by a Competent Person, as defined by OSHA/ANSI, to verify that the equipment is safe for use. In the event of any question or concern regarding the condition of such equipment, users shall remove the equipment from service for further inspection. All users must comply with OSHA/ANSI/ASTM standards prior to and in using such equipment. For more information regarding safe and appropriate use of equipment, please contact Buckingham Manufacturing at 1-800-937-2825.

INTERNATIONAL USERS:

Notwithstanding the above, please know that certain international jurisdictions require manufacturers of equipment to provide customers with a maximum useful lifespan (sometimes referred to as a “Statement of Obsolescence”). To the extent required, Buckingham personal protective equipment manufactured from synthetic fiber materials including but not limited to items such as webbing and/or rope are subject to a maximum useful lifespan of ten (10) years from the date of manufacture. As stated above proper usage, storage, maintenance, and care impacts the useful lifespan of equipment. Extreme circumstances may require that product must be retired after only one use. This statement is made in conformance and compliance with BS EN 365:2004. International users must ensure that product inspections are completed by Competent Persons as defined by international standards including but not limited to British Standard (“BS”). If equipment fails any inspections, it must be immediately withdrawn from service and destroyed. For more information regarding safe and appropriate use of equipment, please contact Buckingham Manufacturing at 1-800-937-2825.

OUR GUARANTEE:

We guarantee the equipment we manufacture to be free from defects in material and workmanship. We will repair any equipment deemed to be defective which is returned to us by the original purchaser. However, this guarantee is void if any product is changed or altered in any way, or if the product is used in a manner other than for which it is intended. This express guarantee supersedes all other expressed or implied guarantees, obligations or liabilities. There are no implied warranties of merchantability or fitness for a particular purpose and as such, all implied warranties are specifically disclaimed.

LIMITATION ON LIABILITY:

In no event will Buckingham or buyer be liable to the other for lost revenues, lost profits or any other indirect, consequential, special or punitive losses or damages, however caused, whether in action for breach of contract, strict liability, tort, or otherwise, even if advised of the possibility of such losses or damages. In no event will Buckingham’s liability exceed the total amount paid by the buyer to Buckingham for the product or equipment giving rise to such claim(s).

Please see other terms and conditions relating to this product at <https://buckinghammfg.com/terms-conditions/>

REGISTRATION:

Before use of the product, ensure to register and confirm the product at www.buckinghammfg.com/register.

BUCKINGHAM MFG.

BINGHAMTON, NY

1-800-937-2825

www.buckinghammfg.com