

BUCKINGHAM MFG.

PN 24021 – BUCK TAIL MINDER INSTRUCTIONS



Warning: Do not use this product if you cannot understand and follow the instructions and warnings that come with it and complete all necessary functions. Please consult with your physician prior to using this product. Do not use this product under the influence of drugs or alcohol.

The BUCK Tail Minder has been designed to be used as a safe and convenient way to take up slack in the tail end of a WPFRD rope inner strap, Adjustable Positioning Lanyard or other rope devices. The Tail Minder can be used on a single strand of rope to be hooked to a breakaway handline hook (Fig. 3). It can also be used to connect the rope back on itself to make a loop that can be hooked onto a breakaway handline hook (Fig. 7), BuckTender (Fig. 8), accessory ring, etc. The Tail Minder is designed to be used on $\frac{7}{16}$ " & $\frac{1}{2}$ " ropes and will disconnect when slight pressure is applied to it. The Tail minder is not to be used in any way for human support.

Attachment Instructions

Attaching to a single tail:

1. Align the rope with one of the Tail Minder openings and press the rope into the slot (Fig. 1 & 2). Note: The openings have been designed to accommodate different styles of $\frac{7}{16}$ " & $\frac{1}{2}$ " rope, therefore some ropes may be more difficult to insert. Rolling the rope back and forth will make it easier to push into the slot.
2. Adjust the Tail Minder to a desired location on the rope and then hook the remaining Tail Minder opening onto a breakaway handline hook to secure the rope tail (Fig.3).



Fig. 1



Fig. 2



Fig. 3

Attaching to create a loop:

1. Align the rope with one of the Tail Minder openings and press the rope into the slot (Fig. 4 & 5). Note: The openings have been designed to accommodate different styles of $\frac{7}{16}$ " & $\frac{1}{2}$ " rope, therefore some ropes may be more difficult to insert. Rolling the rope back and forth will make it easier to push into the slot.
1. Make a loop in the rope and insert the second strand into the other Tail Minder opening (Fig. 7).
3. Adjust the loop to the size needed by sliding the Tail Minder along the rope length and then hook the loop to a breakaway handline hook (Fig. 7), BuckTender (Fig. 8), accessory hook, etc. to secure the rope tail.



Fig. 4



Fig. 5



Fig. 6



Fig. 7



Fig. 8

STATEMENT of OBSOLESCENCE:

Precise “useful life expectancy” or “shelf life” for this product is not specified, as the degree of use, conditions of use, and the degree of care and storage determines useful life. All users maintain responsibility to select proper equipment for the job, be properly trained in its use, and ensure all personnel support equipment passes inspection before each use. Upon evidence of defects, damage or deterioration, all equipment shall be removed from service immediately and tagged or marked as unusable or destroyed. Additionally, all equipment shall be inspected on a regular basis not to exceed one year by a Competent Person, as defined by OSHA/ANSI, to verify that the equipment is safe for use. In the event of any question or concern regarding the condition of such equipment, users shall remove the equipment from service for further inspection. All users must comply with OSHA/ANSI/ASTM standards prior to and in using such equipment. For more information regarding safe and appropriate use of equipment, please contact Buckingham Manufacturing at 1-800-937-2825.

INTERNATIONAL USERS:

Notwithstanding the above, please know that certain international jurisdictions require manufacturers of equipment to provide customers with a maximum useful lifespan (sometimes referred to as a “Statement of Obsolescence”). To the extent required, Buckingham personal protective equipment manufactured from synthetic fiber materials including but not limited to items such as webbing and/or rope are subject to a maximum useful lifespan of ten (10) years from the date of manufacture. As stated above proper usage, storage, maintenance, and care impacts the useful lifespan of equipment. Extreme circumstances may require that product must be retired after only one use. This statement is made in conformance and compliance with BS EN 365:2004. International users must ensure that product inspections are completed by Competent Persons as defined by international standards including but not limited to British Standard (“BS”). If equipment fails any inspections, it must be immediately withdrawn from service and destroyed. For more information regarding safe and appropriate use of equipment, please contact Buckingham Manufacturing at 1-800-937-2825.

OUR GUARANTEE:

We guarantee the equipment we manufacture to be free from defects in material and workmanship. We will repair any equipment deemed to be defective which is returned to us by the original purchaser. However, this guarantee is void if any product is changed or altered in any way, or if the product is used in a manner other than for which it is intended. This express guarantee supersedes all other expressed or implied guarantees, obligations or liabilities. **THERE ARE NO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND AS SUCH, ALL IMPLIED WARRANTIES ARE SPECIFICALLY DISCLAIMED.**

LIMITATION ON LIABILITY:

IN NO EVENT WILL BUCKINGHAM OR BUYER BE LIABLE TO THE OTHER FOR LOST REVENUES, LOST PROFITS OR ANY OTHER INDIRECT, CONSEQUENTIAL, SPECIAL OR PUNITIVE LOSSES OR DAMAGES, HOWEVER CAUSED, WHETHER IN ACTION FOR BREACH OF CONTRACT, STRICT LIABILITY, TORT, OR OTHERWISE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH LOSSES OR DAMAGES. IN NO EVENT WILL BUCKINGHAM’S LIABILITY EXCEED THE TOTAL AMOUNT PAID BY BUYER TO BUCKINGHAM FOR THE PRODUCT OR EQUIPMENT GIVING RISE TO SUCH CLAIM(S).

PLEASE SEE OTHER TERMS AND CONDITIONS RELATING TO THIS PRODUCT AT <https://buckinghammfg.com/terms-conditions/>

REGISTRATION: Before use of the product, ensure to register and confirm the product at www.buckinghammfg.com/register.

BUCKINGHAM MFG. INC.
BINGHAMTON, NY
800-937-2825
www.buckinghammfg.com